



Place cargo tray in trunk area with the logo at the rear of the vehicle as shown. Ensure tray makes full contact with the trunk floor.

Due to shipping method, it may take up to 24 hours of warmth (21 Celsius) to completely form to its intended shape and lie flat.

Vehicle Function Checks

- Confirm rear hatch closes completely
- Close hatch and confirm full connection

Notes:

- It is Important that the cargo tray is not installed in your vehicle if the cargo area carpet is damp or wet, as mildew may result. Therefore, completely dry the carpet out before installing your cargo tray.
- To maintain the luster and non-stick finish of your cargo tray, clean with a cloth as required using mild soap and water.
- Your cargo tray is chemically resistant to most fluids used in normal vehicle maintenance. Great caution must be used when transporting corrosive chemicals. Should a spill occur, the tray should be carefully removed from the vehicle and washed thoroughly to prevent damage. If contact is made, follow chemical manufacturer's instructions and cautions.