# Part Number: PT278-02140

#### **Kit Contents**

Item #	Quantity Reqd.	Description
1	1	Bumper Protector
2	1	Installation Instruction Sheets
3		
4		
5		
6		

#### **Hardware Bag Contents**

Item #	Quantity Reqd.	Description
1		
2		
3		
4		

## **Additional Items Required For Installation**

Item #	Quantity Reqd.	Description
1		
2		
3		
Conflicta		

#### Conflicts

### **Recommended Tools**

Personal & Vehicle	Notes
Protection	
Safety Glasses	
Vehicle Protection	Seat & Floor Covers
Special Tools	Notes
Roller	Hard Rubber or Wood Hand
	Roller, 1" to 3" wide.
<b>Installation Tools</b>	Notes
Masking Tape	1" wide
Clean Lint-free Cloths	
<b>Special Chemicals</b>	Notes
Cleaner	3M <sup>™</sup> Prep Solvent-70

## **General Applicability**

#### **Recommended Sequence of Application**


Item # Accessory

\*Mandatory

#### Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description

## Legend






Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.


These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.





## 1. Vehicle Preparation

- (a) Before working on the vehicle, protect the seats and carpets with covers.
- (b) The work area, protector and vehicle bumper surface temperature must be at least 60°F.
  - (c) Open the rear compartment door.
  - (d) Saturate a clean lint-free cloth with 3M<sup>™</sup>
     Prep Solvent-70 and scrub the top surface of the rear bumper as shown in Fig. 1-1.
  - ▶ NOTE: When cleaning with 3M<sup>TM</sup> Prep Solvent-70 follow the manufacturer's directions. Do not allow cleaner to air dry.
  - (e) Wipe the scrubbed bumper surface with a clean, dry, lint-free cloth.
  - **NOTE:** Once cleaned do not contaminate this surface by touching it with your bare hands.

## 2. Bumper Protector Installation


(a) While carefully holding the bumper protector by its edges, pull the plastic tab at the end of the part to remove the REAR liner from the acrylic foam tape. (Fig. 2-1)





**NOTE:** Once the release liner is removed from the bumper protector, the surface of the foam tape must not be touched!

Issue: C 8/12/13

 $\wedge$ 







- (b) Before installing the protector, align the center diamond locator on the protector to the center mark on the rear bumper of the vehicle. (Fig. 2-2)
- (c) While keeping the bumper protector aligned, lower the right-hand corner until it contacts the bumper and starts to stick. Using a rolling motion, press the rest of the bumper protector to the bumper from right to left. Do not allow both ends of the bumper protector to stick to the bumper before the center touches. Press firmly from left to right on rear lip of protector to insure adhesion. (Fig. 2-3)
- (d) Remove FRONT plastic liner by pulling tab away from the protector. Press protector to secure tape to bumper surface as liner is being removed from left to right. (Fig. 2-4)
- (e) Using the hand roller, firmly roll and apply pressure around the perimeter of the part to ensure complete adhesion of the acrylic foam tape to the bumper surface. (Fig. 2-5)

# ΤΟΥΟΤΑ

**REAR BUMPER PROTECTOR** 

Checklist - these points **MUST** be checked to ensure a quality installation

Check:	Look For:
Accessory Function Checks	
Check visual alignment	Bumper protector should be visually centered left to right. The front edge of the bumper protector should appear visually parallel to the vehicle bumper. The bumper protector lip should align with
Check for proper tape adhesion.	A gap of approximately ½ mm is designed to exist between the edges of the bumper protector and the bumper. No gap is allowed between the tape and the bumper
Vehicle Function Checks           None Required	
<ul> <li><u>Vehicle Appearance Check</u></li> <li>After accessory installation and removal of protective cover(s), perform a visual inspection.</li> </ul>	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)