Preparation

Part Number: PT938-00140 PTR60-89190

Kit Contents

Item #	Quantity Reqd.	Description
1	1	TRD Skid Plate (w/ 2 Bolts)
2	1	Hardware Kit
3	1	Instruction Form

Hardware Bag Contents

Item #	Quantity Reqd.	Description
1	2	Bolt
2		
3		

Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		
2		
3		

Conflicts

KDSS Sway Bar System	(4Runner)
----------------------	-----------

Recommended Tools

Personal & Vehicle	Notes
Protection	
None	
Special Tools	Notes
None	
Installation Tools	Notes
Sockets	10,12,14mm
Ratchet	
Torque Wrench	
Clip Removal Tool	(4Runner Only)
Special Chemicals	Notes
None	

General Applicability

All models w/o KDSS

Recommended Sequence of Application


Item #	Accessory
1	TRD Suspension Kit
2	
3	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

Legend




Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.


These guidelines can be found in the "Accessory Installation Practices" document.


This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.







1. Remove the Front Bumper Lower Cover (4Runner Only).


- stor(a) For FJ Cruiser, proceed to Step2.
 - (b) For 4Runner, remove the clip (circled), 5 bolts and the front lower bumper cover (Fig. 1-1).

TRONT


(c) Discard the cover and fasteners.

2. Remove No.1 Engine Under Cover Sub-Assembly.

(a) Remove and discard the 4 bolts (Fig. 2-1).



(b) Unhook the No. 1 engine under cover subassembly from the vehicle body and discard it (Fig. 2-2).




3. Remove the Bolts From the Member Braces.

- (a) Remove and discard the forward 4 bolts from the member braces (Black Arrows, Marked A, Fig. 3-1).
- **NOTE:** Do not remove the rearward most 2 bolts (Red Arrows, Marked B).
- **CAUTION:** Do not remove the member braces.

4. Install TRD Front Skid Plate.

- (a) Install the TRD Skid Plate to the vehicle using the two front bolts attached on the Skid Plate.
- (b) Install the 2 supplied rear bolts (Fig 4-1).
- (c) Torque all 4 bolts.

S Torque: 30 N·m (306 kgf·cm, 22ft·lbf)



TRONT

TOYOTA 4RUNNER, FJ CRUISER 2014 - TR Checklist - these points MUST be checked to ensure a quality installation.

checkinst these points wies i be checked to ensure	a quanty motanation.
Check:	Look For:
Accessory Function Checks	
Bolt torque	30 N·m (306 kgf·cm, 22ft·lbf)
Vehicle Function Checks	
Vehicle Appearance Check After accessory installation and removal of protective cover(s), perform a visual inspection.	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)