# Part Number: PT278-35075 PT278-00160

### **Kit Contents**

TOYOTA

Preparation

Item #	Quantity Reqd.	Description
1	1	Mini Tie-Downs (2-pack)
2		
3		

### Hardware Bag Contents

	0	
Item #	Quantity Reqd.	Description
1		
2		
3		

## **Additional Items Required For Installation**

Quantity Reqd.	Description
	Quantity Reqd.

#### Conflicts

Tonneau Cover

#### **Recommended Tools**

Personal & Vehicle Protection	Notes
Special Tools	Notes
Installation Tools	Notes
Special Chemicals	Notes

#### **General Applicability**

All Models

#### **Recommended Sequence of Application**

Item #	Accessory
1	
2	
3	

#### \*Mandatory

Page 1 of 4 pages

### Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

#### Legend





2005 -


Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.


These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.





### 1. Install the Mini Tie-Downs.


CAUTION: Do not install Mini Tie-Downs on vehicles equipped with a Tonneau Cover. <u>Damage to the Tonneau Cover may occur and</u> <u>the Tonneau Cover will not latch properly!</u>

(a) Remove (DO NOT DISCARD) the end caps from the side rails (Fig. 1-1).

(b) Push the tie-down loop so that the locking plate is equal with the guide surface (Fig. 1-2).

re TUNDRA

TACOMA



- (c) With the tie-down loop depressed, slide the tie-down into the rails with the hook facing down. The tie-down must be angled to maneuver around the bed post and into the rail. Release the tie-down loop when the locking plate enters the rail (Fig. 1-3).
- (d) Slide the tie-down to the nearest detent position and snap it into place. To move it to another detent position, depress the tie-down loop and slide it to the next detent (Fig. 1-4).

- (e) Rotate the tie-down loop in a clockwise direction until it is tight (Fig. 1-5).
- (f) Repeat Step 1 for the other side.

(g) Reinstall the end caps (RH & LH) (Fig. 1-6).

ΤΟΥΟΤΑ

ТОУОТА

2015 -2007 -

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:	
Accessory Function Checks		
Ensure bed tie-downs are locked into detents	Ensure tie-downs slide into position	
Vehicle Function Checks		
$\square$		
Vehicle Appearance Check   After accessory installation and removal of protective cover(s), perform a visual inspection.	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)	