

Part Number: PT747-03150**Kit Contents**

Item #	Quantity Req'd.	Description
1	1	Applique, RR Bumper

Hardware Bag Contents

Item #	Quantity Req'd.	Description
1		

Additional Items Required For Installation

Item #	Quantity Req'd.	Description
1		

Conflicts

--

Recommended Tools

Personal & Vehicle Protection	Notes
None	
Special Tools	Notes
Squeegee	4" (3M™Gold)
Low Friction Sleeve	3M SA-1
Surface Thermometer	Infrared Non-contact
Heat Gun	Master Heat Gun HG-301A or equivalent
Installation Tools	Notes
Lint Free Rags	
Spray Bottle	For wetting agent
Special Chemicals	Notes
Cleaner	VDC approved cleaner and cleaning method
Wetting Agent Note: Solution depends upon ambient temperature of the part and the vehicle surface. If it is difficult to remove bubbles with a squeegee, add one more ml. of shampoo.	Johnson's Baby Shampoo mixed in one liter of water: At 65°F add 2 ml. shampoo At 70°F add 3 ml. shampoo At 80°F add 3.5 ml shampoo At 90°F add 4 ml. shampoo

General Applicability

--

Recommended Sequence of Application

Item #	Accessory
1	

*Mandatory

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Req'd.	Description
1		

Legend**STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.**OPERATOR SAFETY:** Use caution to avoid risk of injury.**CAUTION:** A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.**TOOLS & EQUIPMENT:** Used in Figures calls out the specific tools and equipment recommended for this process.**REVISION MARK:** This mark highlights a change in installation with respect to previous issue.**SAFETY TORQUE:** This mark indicates that torque is related to safety.

Procedure

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.

1. Prepare the Vehicle.



- (a) The part and vehicle surface temperature must be maintained between 65°F and 90°F for optimum installation. Store parts flat at room temperature in a clean dry place.




- (b) Clean the entire application surface to remove grease and wax. Clean the entire area with a VDC approved cleaner and cleaning method.


- (c) Wipe the cleaned surface with a clean, dry, lint-free cloth.

2. Install the Rear Bumper Protector.




- (a) Place the part face down on clean flat surface. Remove the entire liner (Fig. 2-1).







- (b) Spray the bumper with wetting agent. Avoid over-spraying into the trunk (Fig. 2-2).



- (c) Align the center notch directly below the striker latch opening and the leading edge of the premask along the ridge of the bumper being sure not to roll over the ridge. Do not smooth the part with hands (Fig. 2-3).




- (d) Spray the premask with wetting agent. Avoid over-spraying into the trunk (Fig. 2-4).




- (e) Use long, smooth, overlapping strokes with a squeegee from the center of the horizontal section outwards and begin to wrap over bumper (Fig. 2-5).

- (1) Do not use excessive force as it may cause creasing of the protector.




- (f) Carefully remove the premask paper 180° against itself prior to squeegeeing the final wrap area. (Fig. 2-6).



- (g) Use a sharp squeegee with a protective sleeve (optional) to make smooth, overlapping, downward strokes from the center outwards on the final wrap area of the vertical section (Fig. 2-7).
- (h) Dry off the vehicle with a clean, lint free rag.

TOYOTA CAMRY 2015 - REAR BUMPER APPLIQUE

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
<u>Accessory Function Checks</u> <input type="checkbox"/> Proper adhesion – Visual  <input type="checkbox"/> Proper adhesion – Physical <input type="checkbox"/> Proper alignment – Cross-Car	 Look for bubbles, loose and lifting edges. With light pressure rub hand over top of part and if crackling sound occurs, resqueegee. If bubbles cannot be worked out to the nearest edge, replace part. Part must be centered within bumper +/-3 mm.
<u>Vehicle Appearance Check</u> <input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.	 Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMS Accessory Quality Shipping Standard.)