

Preparation

Part Number: PT347-47101

NOTE: Part number of this accessory may not be the same as the part number shown.

Kit Contents

Item #	Quantity Req'd.	Description
1	1	Convenience Net
2	1	Hardware bag
3	1	Installation Instructions







Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Req'd.	Description
1	2	Screw grommet (90189-05168)

Hardware Bag Contents

Item #	Quantity Req'd.	Description
1	2	Hook

Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.
	SAFETY TORQUE: This mark indicates that torque is related to safety.

Additional Items Required For Installation

Item #	Quantity Req'd.	Description
1	N/A	

Conflicts

None

Recommended Tools

Personal & Vehicle Protection	Notes
Special Tools	Notes
Installation Tools	Notes
Screwdriver, Phillips	#3
Special Chemicals	Notes

General Applicability

All

Recommended Sequence of Application

Item #	Accessory

*Mandatory

Procedure

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:-

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.




Fig. 1-1

1. Installation of hooks

- (a) Open the rear cargo door and locate the panel shown on the passenger's side of the vehicle. (Fig. 1-1)




Fig. 1-2

- (b) Remove screw using a #3 Phillips screwdriver as shown. (Fig. 1-2)

Procedure




Fig. 1-3

- (c) Select one of the hooks and insert the screw through the hole of the hook. Re-install the removed screw (with hook) into the panel recess. (Fig. 1-3) Ensure the hook is located on the bottom of the opening and tighten with the #3 Phillips screwdriver.

DO NOT OVER-TIGHTEN SCREW IN PLASTIC GROMMET

- (d) Repeat steps 1(b) & 1(c) on the driver side of vehicle




Fig. 2-1

2. Installation of Cargo Net

- (a) Orient the net so the pull-tab is facing towards the rear of the vehicle and install the bottom hook over the passenger side lower D-ring as shown. (Fig. 2-1)




Fig. 2-2

- (b) Install the upper bungee loop over the passenger side hook as shown. (Fig. 2-2)
- (c) Repeat steps 2(a) & 2(b) for the driver side of vehicle.




Fig. 2-3

(d) Completed assembly as shown. (Fig. 2-3)

Checklist - these points **MUST** be checked to ensure a quality installation.

<u>Check:</u>	<u>Look For:</u>
<p><u>Accessory Function Checks</u></p> <p><input type="checkbox"/> Correct orientation of hooks.</p> <p><input type="checkbox"/> Confirm the net is attached properly to the anchor points in the vehicle.</p> <p><input type="checkbox"/> Pull Tab orientation.</p>	<p>Insure hooks are located in the bottom of the recessed opening after the screw is tightened.</p> <p>Make sure the net hooks are attached to the lower d-rings and the loops are attached to the hooks at the top.</p> <p>Make sure the net's plastic pull tab is facing rearward.</p>
<p><u>Vehicle Function Checks</u></p> <p><input type="checkbox"/> Rear cargo door.</p>	<p>Rear cargo door should open and close freely without interference from cargo net.</p>