

Part Number: PU060-0T013-P1

Kit Contents

Item #	Quantity Reqd.	Description
1	1	Front Passenger Side Mudguard
2	1	Front Driver Side Mudguard
3	1	Rear Passenger Side Mudguard
4	1	Rear Driver Side Mudguard
5	2	Hardware Kit
6	1	Instruction Sheet (Electronic Copy)

Hardware Bag Contents

Item #	Quantity Reqd.	Description
1	2	#10 x 15 mm Screws (short)
2	10	#10 x 19 mm Screws (long)
3	6	#10 Spring Clips
4	2	#14 x 19 mm Screws
5	2	Insert

Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		
2		
3		

Conflicts

Note: Ground effects

Recommended Tools

Personal & Vehicle Protection	Notes
None	
Special Tools	Notes
None	
Installation Tools	Notes
Screwdriver	Phillips #2 & 3, Slot
Drill	Standard/Right Angle
Drill Bit	6 mm (1/4")
Clean Cloth/Rag	
Special Chemicals	Notes
Cleaner	Soap & Water Mixture

NOTE: Part number of this accessory may not be the same as the part number shown.

General Applicability

--

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory





Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CAUTION: A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.
	TOOLS & EQUIPMENT: Used in Figures calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.
	SAFETY TORQUE: This mark indicates that torque is related to safety.

Care must be taken when installing this accessory to ensure damage does not occur to the vehicle.
The installation of this accessory must follow all instructions and use supplied hardware to ensure an approved quality installation.



1. Clean Front Mounting Area

-  (a) Clean and degrease front body panel where mudguard is to be located with a clean cloth and soap/water mixture.

2. Removal of Existing Hardware

-  || (a) For 2009-2010 remove existing screws, locations A and B. **DO NOT DISCARD** (Fig 2-1a)
-  || (b) For 2011 + vehicles remove existing push pin, location A and discard. (Fig 2-1b)
- || (c) For 2011 + vehicles install supplied insert location A (Fig 2-2)

3. Installation of Front Mudguard

- || (a) Mount mudguard on body panel and install existing & supplied screws in locations A and B while holding part up and into body panel. (Fig. 3-1)

4. Installation of Lower Mount Holes

-  (a) Install supplied 15mm (short) self tapping screw in location C while holding part up and into body panel (Fig. 4-1).
- (b) Install supplied 19mm (long) self tapping screw into location D while holding part up and into body panel. (Fig. 4-1)
- (c) Repeat procedure for other side


NOTE: For easier accessibility wheels can be removed or use a right angled drill.

5. Clean Rear Mounting Area

-  (a) Clean and degrease rear body panel where mudguard is to be located with a clean cloth and soap/water mixture.


6. Mount Hole Preparation


-  (a) Mount mudguard, using part as a template, drill 6mm (1/4") holes in panel edge at locations A, B and C while holding part up and into body panel. Fig. (6-1).
-  (b) **IMPORTANT:** Make sure mudguard is seated in the correct position before drilling. If holes are too low, gapping will occur.



7. Installation of Spring Clips

-  (a) Install supplied spring clips over panel edge holes location A, B and C with turned up edge on inside of panel. (Fig. 7-1)






8. Installation of Mudguards

- (a) Mount mudguard and install supplied screws 19mm (long) in locations A, B and C. Tighten screws while holding mudguard up and into body panel.



(Fig 8 -1)



- (b) While holding mudguard up and into body panel install supplied self tapping screw 19mm (long) in location D. DO NOT OVERTIGHTEN (Fig 8-2).



- (c) Repeat procedure for other side.

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:

Look For:

Accessory Function Checks

Gaps between mudguards and body side

Excessive gaps greater than 1.0 mm.